

Korado Radiator Brackets Install Guide



Make it Click

There is a trick to secure these Easyfit brackets to your radiator. The claw needs to be pressed down until you hear a defined **CLICK** sound from the bracket. This sound comes from the plastic insert teeth locking and securing the bracket in place.

Watch the video →



Mounting

These radiators are supplied with Easyfit brackets. These can be mounted anywhere along the length of the radiator as they simply clip to the top and bottom edge.

Attaching the brackets

- The plastic safety clip prevents the radiator from unhinging. There are teeth on the plastic safety clip that hold the radiator securely.
- Simply align the bracket to the bottom and top edge of the radiator.
- Push the top down to the edge of the radiator. You will notice that the bracket is loose.
- Align your hands on the top and bottom of the radiator brackets and press down until you **Make it Click**. This sound is made when your plastic safety clip secures in place.
- The bracket now holds securely to the radiator.
- To release the bracket push on the back of the safety clip and push away - the safety clip will release and your bracket will be loose again.
- Wall fixing stud position is flexible but we recommend 150mm in from each end of the radiator.

Note: 1800mm wide radiators will be supplied with an additional set of brackets.

